

# MAX ACCESSORIES

## Remote Controls and Wireless Keyless Entry System

Maximized Sales. Optimized Inventory.

Make sure you have the LiftMaster® Remote Controls and Wireless Keyless Entry Systems your customers need. MAX Accessories are backwards compatible with all LiftMaster Garage Door Openers, Gate Operators and Commercial Door Operators manufactured since 1993, so you can streamline your inventory and increase your margins.

### MAX 3-Button Remote Controls

(895MAX, 893MAX and 890MAX)



(895MAX)



(893MAX)



(890MAX)

- Program up to three Garage Door Openers, Gate Operators, Commercial Door Operators or MyQ® Light Accessories.
  - Safeguard homes or businesses with **Security+ 2.0®**, which sends a new code with every click of the remote control.
  - Compatible with all LiftMaster Garage Door Openers, Gate Operators and Commercial Door Operators manufactured since January 1993.
- ✓ **895MAX**—Bright blue LED buttons make night operation easy.
  - ✓ **893MAX**—Different-sized buttons for quick and easy activation.
  - ✓ **890MAX**—Fits on a keychain or in a purse or pocket.



### Wireless Keyless Entry System (877MAX)

- Opens or closes the garage door without using a remote control or key.
- Uses a four-digit PIN code and can control up to 24 openers/operators.
- Generates temporary codes for friends and service people.
- Installs wirelessly for easy setup.
- Closes the garage instantly with one-press activation. (2005 to present)
- Compatible with all Garage Door Openers manufactured by LiftMaster since January 1993.

### Tips for Selling the MAX Line

An installation is a great time to get your customers to purchase additional accessories. With that in mind, here are a few conversation starters to help you promote the MAX line of products.

#### For Remote Controls

- Do you need additional remote controls for other vehicles or people at your home or business?
- Do you need a remote to control more than two Garage Door Openers, Gate Operators or Commercial Door Operators?
- Would you like to replace a lost or broken remote?
- Do you want to control home lighting with your remote control\*?

#### For Wireless Keyless Entry

- Would you like to go on a run or walk your dog and leave your keys at home?
- Would you like to give others access to your garage without giving them keys?
- Would you like to be able to give delivery or service personnel temporary access codes to your garage?

\*Requires additional purchase of MyQ Light Accessories.

### MAX Compatibility Chart

Garage Door Opener Manufacture Year	1993–1995	1996–2005	2006–2014	2011+
Learn Button Color	Green	Orange/Red	Purple	Yellow
Code Frequency	Billion Code	Security+®	Security+	Security+ 2.0®
	390 MHz	390 MHz	315 MHz	310, 315, 390 MHz
Garage Door Opener Model Numbers	1245/1255 1270/1280	1245R/1255R 1265R 2220 2245 2255 2265 2280 2500 2575 2585 2595	1345/1355 1356 3220 3255 3240 3265-3267 3270 3280 3500 3575 3585 3595 3800 3850	8065 8155 8165 8355 8360 8365-267 8500 8550 8557 8587

### Advanced Programming for Remote Controls

<b>1.</b>	Press the program button on the remote control until the LED on the front of the remote control turns on.
<b>2.</b>	Press and release the remote control button that you wish to use the number of times that corresponds with your garage door.  Number of presses: 1—310, 315, 390 MHz Security+ 2.0 (yellow button) 2—315 MHz Security+ (purple button) 3—390 MHz Security+ (red/orange button) 4—390 MHz Billion Code (green button)
<b>3.</b>	Press another button (other than the one selected in step 2) to lock the code type into the remote control memory.
<b>4.</b>	Press and release the Learn button on the Garage Door Opener.
<b>5.</b>	Press and hold the button chosen in step 2 until the remote control LED goes out or until the Garage Door Opener lights flash.

### Advanced Keypad Programming

<b>1.</b>	Press and hold the * and # keys until the LEDs stop flashing.
<b>2.</b>	Enter the customer four-digit code and press #.
<b>3.</b>	Press the number "X" key and then press #.  "X" = 1 for 315 MHz Security+ (purple button) 2 for 390 MHz Security+ (red/orange button) 3 for 390 MHz Billion Code (green button) 4 for 310, 315, 390 MHz Security+ 2.0 (yellow button)